

## I.F. Alignment

- Connect the output from Signal Generator through a 200 MMFD Mica Condenser to the Antenna wire at the rear of the Loop Antenna.
- 2. Connect output meter across speaker voice coil.
- Set volume control at maximum clockwise rotation and tuning condenser with plates fully out of mesh.
- 4. Adjust Signal Generator to 455 KC.
- 5. Adjust top and bottom iron cores of 2nd I.F. Transformer for maximum output.
- 6. Adjust top and bottom iron cores of 1st I.F. Transformer for maximum output.
- 7. For best results this procedure should be repeated with the Signal Generator set for lowest usable output.

## R.F. Alignment

- Connect Signal Generator and output meter as above.
- 2. Adjust the Signal Generator and receiver to 1500 KC.
- 3. Adjust the Oscillator Trimmer (centre section of gang) for maximum output.
- 4. Adjust the Antenna Trimmer (front section of gang) for maximum output.
- 5. Adjust the Mixer Trimmer (centre section of gang) for maximum output.

The last two adjustments are very critical therefore make the adjustments carefully using low output from Signal Generator.

## **ADDISON 64**

